

Maryland State Highway & Baltimore City General Conditions for Hauling Permits

1. This permit does not give the permittee the right to move over highways or bridges under the jurisdiction of any city, county or municipality, nor over railroads or railways, except to cross such highways or bridges, or railroads or railways, at grade, after giving sufficient notice to and making appropriate arrangements with responsible authorities; nor does it authorize the permittee to use or damage private property in anyway. The permittee shall comply with all rules posted on any bridge or road traversed. Any damage caused directly or indirectly to any road surface, bridge or other structure, whether maintained by City of Baltimore, Maryland State Highway Administration or by another , by the operation of the vehicle, is the responsibility of the permittee. Damage to structures under its jurisdiction shall be repaired by the City of Baltimore or State Highway Administration at the expense of the permittee.
2. This permit or approved substitute shall be carried in the vehicle moving under its authority and shall be open for inspection by any City, State, county municipal, or other public official, or to any person involved in an accident in which the vehicle played a part.
3. The permittee shall give strict attention to safety and rights of public travel and shall yield the right of way to passing traffic in either direction. Arrangements must be made in advance for adequate flag-persons or police to be present when any narrow bridge is crossed.
4. No move which is expected to disturb any overhead wires, cables, signal or traffic lights, limbs of trees, or other structures may begin, until the permittee obtains permission and makes arrangements with owners thereof.
5. NO permit for overweight may be issued to or used by a vehicle and load which can be dismantled or disassembled so that together they are not overweight, or a vehicle which is neither special mobile equipment nor 5 axles vehicle, or a vehicle registered in Maryland which is not registered for the maximum permissible gross weight.
6. Every vehicle and load which together are overweight shall be stripped of as much excess weight as possible, and every vehicle and load which together are oversize shall be reduced in size as much as possible.
7. The permit is granted under and subject to the vehicle laws of Maryland and to all applicable general and specific conditions for operating oversize and overweight vehicles, as promulgated and published by the State Highway Administration and by the City of Baltimore. As set out in part of this section of this permit, and as specified in part in the preceding sections of this permit. Those laws and conditions must be complied with in all respects. Any false statement of a material fact on the permit application may result in the denial of future permits to the permittee. No compliance with specific restrictions stated in the preceding sections of this permit renders this permit subject to immediate revocation and confiscation by any duly appointed representative such as city, county or state police .

Note the permit is subject to favorable road and weather conditions. The permit is not valid when snow emergency plan is in effect for specified area.